


REALFORCE TKL for Mac USER'S MANUAL



Indicator LED

- **capslock**
Light up when Caps Lock is on.
(According to the connected host / Basically OFF)
- **win mode**
Light up when Windows Mode is on. (Initially OFF)
- **key lock**
Light up when Key Lock is on. (Initially OFF)
- **☀ ⇄ F1**
Light up when Mac Special Function Switch is on. (Initially OFF)
Only keys with Mac special functions can be exchanged between F1 to F12.

APC Setup *2*3



- home Keylock On/Off *2
- page up Indicator LED Color *2
- end Windows Mode Switch *2
- page down Indicator LED Brightness *2

Switch of Mac Special Key ⇄ [Fn] Key

Installation of Software

Go to www.realforce.co.jp to download software for the setup of LED color and APC function (adjust the ON position). Execute and install by following the instructions.



www.realforce.co.jp

*1 ... To adjust the brightness of an official Apple display that connects to a Mac Pro or Mac mini, use the F14 (dark) and F15 (bright) keys instead of the F1 and F2 keys.


*2 ... Works by pressing the [Fn] Key.

*3 ... Only available on keyboards with APC function.

The initial setup of Mission Control [F3] and Launchpad [F4] are not functional. But, it can be used in the Mac OS environment. Refer to the instruction manual for the setting method.

Specification of Keyboard in Windows Mode

*Keys without indications function as per printing on key.



- *1 ... Works by pressing the [Fn] Key.
- *2 ... Only available on keyboards with APC function.

Some keys are not functionable when using Windows Mode in the Mac OS environment. Do not use Windows Mode on Mac OS.

